

Aluminum Railing Gate Installation Instructions

To determine the size of gate needed - measure from the inside of post to the inside of post. This will be your **net clear opening**. Order the gate according to this opening measurement. Gate will be **manufactured to fit in this opening allowing for 3/4" on each side** for hardware sold by Arndt & Herman.

To install pre assembled gate, attach hinges on one side with the screws that are provided. Allow for a 2 in gap at the bottom of gate. Line up top rail with railing, then screw hinges to post. Attach latch on opposite side of gate.

For installation of hardware, see installation instructions provided with gate hardware.

Our stock gates are 36" (nominal) / 34-1/2" (actual) and 48" (nominal) wide / 46-1/2" (actual) – designed to use on two posts with net clear opening of 36" and 48", respectively.

By making sure the posts end up with these measurements – you will be able to use a standard, stock gate and will not have the extra expense and time to wait on a gate manufactured to your exact measurements.