

Care and Cleaning of your Sheerline® Products

Sheerline[®] Products resist most common household stains, but like other outdoor products it will get dirty when exposed to the atmosphere. Cleaning with common household cleaning solutions and water is recommended to keep your Sheerline[®] Products looking like new. For tougher stains or scuffs, Greased Lightning[®] or SoftScrub[®] may be used. Mildew may be removed with a commercially available mildew remover or 25% concentration of Clorox[®] in water along with household detergent. For other questions or comments, please contact us.

Note: Chemical agents may be hazardous to the user or environment. Please follow all precautions and warnings on product labels.